

# **UPS Monitoring Software**

## **User Manual**

### **Emily2**

*For*

*Microsoft Windows 2000*

*Microsoft Windows XP*

*Microsoft Windows Server 2003*

*Microsoft Windows VISTA*

*Microsoft Windows 7*

*Microsoft Windows 8*

*Microsoft Windows Server 2008 R2*

*Microsoft Windows Server 2012*

*Microsoft Windows 10*

*Microsoft Windows Server 2016*

# Table of Contents

<b>1.</b>	<b>Installation &amp; Settings .....</b>	<b>2</b>
1.1	Note.....	2
1.2	Installation Instructions.....	2
1.3	Instructions on Removing ECUS Program .....	5
<b>2.</b>	<b>Function Descriptions .....</b>	<b>6</b>
2.1	Real-Time Information Monitoring Display .....	6
2.2	Control .....	11
2.3	Import/Export Setting .....	11
2.4	General Setting.....	12
2.5	SMS.....	18
2.6	E-Mail Settings .....	20
2.7	Data Log.....	21
2.8	Event log .....	23
2.9	Schedule.....	25
2.10	Oscillograph.....	29
2.11	Power Abnormal Alarm .....	30
2.12	About.....	30

# 1. Installation & Settings

## 1.1 Note

- Operating OS: Windows 2000 / XP / Server 2003 / Vista / 7 / 8 / Server 2008 R2 / Server 2012 / 10 / Server 2016.
- Other Software Conditions:
  1. MDAC 2.8. (windows 2000 Only)  
<http://www.microsoft.com/downloads/details.aspx?familyid=6C050FE3-C795-4B7D-B037-185D0506396C&displaylang=en>
  2. For Windows Installer 3.0 and above.
  3. For Framework 2.0 and above.
- Peripherals: Use either a serial port or USB.

## 1.2 Installation Instructions

**1.2.1** Please login as an Administrator.


**1.2.2** Double click to execute “Setup”.




**1.2.3** Click “Next” to next step.




**1.2.4** Enter “Select Installation Folder” to select the desire location for Emily program. (Default: C:\Program Files\Emily2.) Choose the user (yourself or anyone) who uses this software.Click “Next” to next step.




**1.2.5** Enter “Confirm Installation” to ensure the completed installation of Emily2. Click “Next” to next step.



1.2.6 Installing Emily2 program.



1.2.7 Click “Close” to end the installation.




## 1.3 Instructions on Removing Emily2 Program


Remove Emily2

**Step1.** Go to Windows Control Panel and select “Add or Remove Programs”.


**Step2.** Select “Emily2” and click “Remove”.



**Step3.** In the page shown below, click “Yes” to confirm removal of the Emily2 or click “No” to cancel the removal.



**Step4.** When the progress bar run to finish, It's complete the removal. Emily2 Icon will disappear in the “Add or Remove Programs” page.




## 2. Function Descriptions

Emily2 program is user-friendly UPS monitoring software which reveals the status of the UPS via USB or RS232 for up to 4 parallel units. It provides easy to read real time metering of important UPS parameters such as input/output voltage, frequency, UPS temperature, loads & battery capacity. These UPS parameters & status information are recorded and presented in both graphically and numerically.

The “Schedule” function of Emily2 allows user to preset various UPS commands to perform repetition of tasks automatically. In event of Power outage or abnormality, Emily program is capable of automatically informing user via SMS & email instantly and closes application software. The following chapters will provides detailed descriptions of these superior features of Emily2 program.

### 2.1 Real-Time Information Monitoring Display



## A. Tools Field

Function	Descriptions	Remarks
Control	This function include: Self Test, UPS Shutdown. In this function, you can send command to unit in this time.	
Setting	There are 3 parts in this item: “General Setting”, “SMS Setting”, And “Email Setting”.  1. “General Setting”: setting of Communications, Multi language, Setting of Shutdown. 2. “SMS Setting”: SMS alert function set up. 3. “E-mail Setting”: E-mail alert function set up.	
Data Base	There are 2 parts in this item: “Event Log” And “Data Log”.  1. “Event Log”: Provides a list of records of events, command entries, alarms, etc. 2. “Data Log”: Stores the UPS operating parameters monitored & recorded by the Emily2.	
Schedules	Provides scheduling of to-do events and commands.	
Oscilloscope	Graphical overall of the recorded UPS parameters data.	
About	Record the version number and proprietor name of the Emily2.	

## B. Parallel Unit Information

Provides input/output voltage, frequency, loads of UPS parameters for up to 4 parallel units at the same time.

## C. Real Time Information

When you select unit in Parallel Unit Information zone, the details of UPS parameters will show on this zone.

This zone includes: “Icon page”, “Value page”, “Rating Information”, and “Machine Information”.

### C1. Rating Information


Provides rating information of the connected UPS such as Rating Voltage, Rating current, Battery Voltage, and Frequency.

### C2. Machine Information

Provides machine information of the connected UPS such as Manufacturer, UPS Model, and Firmware Version.







Power Flow page :




※ Symbols Description



State	Symbols	Description	Remarks
Boost		Non-Boost	
		Boost	
Buck		Non-Buck	
		Buck	
Over Load		Non-Over Load	
		Over Load	
Battery State		Non-Battery Disconnect	
		Battery Disconnect	













Battery State		Battery OK	
		Battery Low	
By Pass		Non-By Pass	
		By Pass	

Meter Page:




※ Symbols Description

State	Symbols	Description	Remarks
Connection State		UPS connected. This symbol represent when the UPS is successfully connect to the Computer.	
		UPS disconnected. The connection between the UPS & the Computer is disrupted.	

<b>Power State</b>		Power Supply OK.	
		Power Failure. The utility supply is absent or abnormal conditions.	
<b>UPS Battery State</b>		Battery Level OK.	
		Battery Low. The UPS battery is near to end of discharge or is at low power level. (2 Icon swap)	
			
		UPS Battery Failed.	
<b>UPS Models</b>		ON LINE Model.	
		OFF LINE Model.	
<b>Test State</b>		UPS No Testing.	
		UPS Testing.	
<b>By Pass</b>		By Pass mode. (2 Icon swap)	
			

# 2.2 Control




Provides command to UPS for self-test, battery discharge test, stop test, shut-down, stop shut-down and OS for shut-down, stop shut-down.

# 2.3 Import/Export Setting


## 2.3.1 Import Setting

Select the Setting file which you want to Import.  
Click “Open” to Import the Setting.




### 2.3.2 Export Setting


Select Export Folder and click “Save” to save this Setting.



## 2.4 General Setting

Allows user to select & set the connecting Com port or Remote, UPS or OS shutdown, etc.





#### 2.4.1 Setting amount of unit, and choose the Protocol.

Total Unit of Machine  Protocol

#### 2.4.2 Setting number of unit, and unit name which show on the Real Time Information Monitoring Display form.


Name	<input type="text" value="Machine 1"/>	Machine Number	<input type="text" value="1"/>
	<input type="text" value="Machine 2"/>	Machine Number	<input type="text" value="2"/>
	<input type="text" value="Machine 3"/>	Machine Number	<input type="text" value="3"/>
	<input type="text" value="Machine 4"/>	Machine Number	<input type="text" value="4"/>

#### 2.4.3 Setting Interface and Com Port of connection.

Communication Interface  Com Port

Baud Rate


#### 2.4.4 Data log record setting



Data Log Record: ☒ per 10 secs  
Maximum Record: Unlimited

Select the item to enable the data log record, then set record interval time. And set data storage count of record list.


#### 2.4.5 Language Selections



Language English

The Emily2 program provides various major languages for user selection. The initial start up language will be English.


#### 2.4.6 Data retention setting



Days of data retention 0 (0:Never Delete)

The period of time user intends to save the data in database. If the value is “0”, means data in database never delete.

#### 2.4.7 Remote Setting



Remote Setting


☒ Connect Local Machine  
☐ Connect Remote Machine

IP:

If you want to remote other computer, please choose “Connect Remote Machine”, and insert IP. If choose “Connect Remote Machine”, you can’t send command, scheduling and Shutdown the UPS, but can Shutdown the computer.


#### 2.4.8 Enable ACPI Shutdown

When Enable ACPI Shutdown, all of the Shutdown functions controlled by ACPI.




☒ Enable ACPI Shutdown   
☐ Emily2 Shutdown for OS

Pop up Warning Message.



Power buffer times arrange.





2.4.9 Shutdown Type

OS Shutdown Type: 

Shutdown

If the shutdown type selects “Hibernate” as OS it's.

2.4.10 Auto save Application

Provides a function to save program when OS shutdown.

☐ AutoSave Application Status

Saved Log

☐ Display Closed Files Record on Emily2 Restart


Auto close and save Application Files before OS shutdown.

☐ AutoSave Application Status

When restart Emily2, Pop up the list of Closed Files.

☐ Display Closed Files Record on Emily2 Restart

“Record Log”



Save AutoSave Directory under My Document.

Documents library

Includes: 2 locations

Arrange by: Folder

Name	Date modified	Type	Size
AutoSave	3/25/2014 3:04 PM	File folder	

#### 2.4.11 Optional command file to execute after OS started countdown

Select a desire time to execute specific file automatically after OS started Shutdown.  
20 min at Max.

☐ Optional command file to execute after OS started countdown  Minute  
Max: 20 minutes

#### 2.4.12 When Power Failure , OS Shutdown Buffer Time

☐ When Power Failure, OS Shutdown Buffer Time (Range:1-2880)  Minute

Select a sufficient time for the computer OS to automatically shutdown when a power outage occurred. The selectable time is from 1 min. to 2880 min.

#### 2.4.13 When Battery low , OS Shutdown Buffer Time

☐ When Battery Low, OS Shutdown Buffer Time (Range:0-600)  Minute

Select a desire time to automatically shutdown the computer OS before the UPS battery power is depleted. The selectable time is from 0 min. to 600 min.

#### 2.4.14 When Battery capacity Low than , OS Shutdown Buffer Time

☐ When Battery capacity Low than  % (0-100%)  
OS Shutdown Buffer Time (Range: 1-600)  Minute

Select a desire time to automatically shutdown the computer OS before the battery capacity is lower than xx %.The selectable time is from 1 min. to 600 min.

#### 2.4.15 Action When Utility Recovery

When Utility Recovered,

When utility recovers, continue or cancel the countdown of OS shutting down.

#### 2.4.16 Turn off UPS

☒ Turn Off UPS  
Time Needed for Shutdown Sequence Before UPS Turns Off :

Time needed for shutdown sequence before UPS turn off

## 2.5 SMS

An alert message of recorded event will be sent to a predetermined mobile phone number via a subscribed short message service provider.

**SMS Setting**

SMS Server:

ID:  API ID:

PassWord:

Phone Number:

**A**

**Send Setting**

<input type="checkbox"/> UPS Connected	<input type="text" value="SMS message UPS connect"/>
<input type="checkbox"/> UPS Disconnected	<input type="text" value="SMS message UPS disconnect"/>
<input type="checkbox"/> Shutdown OS	<input type="text" value="SMS message System shutdown"/>
<input type="checkbox"/> Power Fail	<input type="text" value="SMS message Power failure"/>
<input type="checkbox"/> Battery Low	<input type="text" value="SMS message Battery low"/>
<input type="checkbox"/> Power Restored	<input type="text" value="SMS message Power restored"/>
<input type="checkbox"/> UPS Shutdown	<input type="text" value="SMS message UPS shutdown"/>
<input type="checkbox"/> Over Load	<input type="text" value="SMS message Over load"/>
<input type="checkbox"/> Battery Failed	<input type="text" value="SMS message Battery weak"/>
<input type="checkbox"/> UPS Self Testing	<input type="text" value="SMS message UPS test"/>

**D**

This SMS function is only available through third-party Short Message Service Providers. To use this function you need to subscribe an account on [every8d] or [clickatell]. These are currently the only 2 third-party SMS providers supported by Emily2 program. For more information on subscriptions and charges, please go to their respective website as follow:

1) For [Every8d] : Go to <http://www.every8d.com/>.

**Note :** Please subscribe as “Corporate” account in order to use Emily2 program SMS function.

2) For [Clickatell] : Go to <http://www.clickatell.com/>

**Note :** Payment has to be made to obtain an “api\_id” before use.

**A. Send Test :**

Click to send a test message to confirm the settings.

**B. Account Settings :**

Insert the SMS provided name, ID, passwords, “api-id” (for Clickatell subscriber only) and mobile phone number (international dialing format, include “+” or “00” and country code).

**Note :** If you want to send message to more than 1 mobile phone number, must use “, ” to separate mobile phone numbers.

**C. Event & Message Selections :**

Click to select the desire Events to be broadcasted and the respective message contents (You may change and retype the Message contents to meet your requirement in English).

**D. Save Setting :**

Click “OK” to save & apply settings

**Note :** Internet Firewall may not allow this SMS function. If you have installed Firewall please allow this function.

# 2.6 E-Mail Settings

B

User Name: Emily2

User Email Address: XX@XXX.XXX

Password: \*\*\*\*\*

SMTP Server: XXX.XXX.XXX

SMTP Server Port: 25

Receiver Name: User

Mail To: XX@XXX.XXX.XXX

Subject: Hello

A

Email Test

C

UPS Connected

Mail message UPS connect

UPS Disconnected

Mail message UPS disconnect

Shutdown OS

Mail message System shutdown

Power Fail

Mail message Power failure

Battery Low

Mail message Battery low

Power Restored

Mail message Power restored

UPS Shutdown

Mail message UPS shutdown

Over Load

Mail message Over load

Battery Failed

Mail message Battery weak

UPS Self Testing

Mail message UPS test

D

OK

Cancel

## A. Sent Test :

Click to send a test message to confirm the settings are correct.

## B. Account Settings :

Insert the User Name (Sender, e.g. Emily2), User Email Address (select a sender email address specifically for this function), Password (the pass word of your email server), SMTP Server (insert SMTP server or IP address), SMTP Server port (port of SMTP Server), Receiver Name (select a predetermined email address the event messages will be sent to), Mail To (Mail address of receiver), and Subject (select a subject name to acknowledge the receiver).

**Note :** If you want to send email to more than 1 email address, must use “ ; ” to separate email addresses.

## C. Send Setting :

Click to select the desire Events to be broadcasted and the respective message contents (You may change and retype the Message contents to meet your requirement in English).

## D. Save Setting :

Click “OK” to save & apply settings.


**Note :** Internet Firewall may not allow this E-Mailing function. If you have installed Firewall please allow this function.

## 2.7 Data Log

The “Data Bank” stores all UPS operating parameters monitored & recorded by the Emily2 program.

It facilitates the recorded data (include Input Voltage, Output Voltage, Input Frequency, Battery Capacity, Temperature, Load) for a more effective study of the desire information.

The information in the Data Base can be exported to Excel file.



The screenshot shows a window titled "Data Log" with a search bar at the top. The search bar includes a dropdown for "Machine Name" (set to "Machine 1"), a text field for "Date" (set to "2016/08/04"), and an "Update" button. Below the search bar is a "Work Progress" progress bar and three buttons: "Export", "First", and "Last". The main area of the window contains a table with the following columns: Time, Input Voltage, Output Voltage, UPS Load, Input Frequency, Battery Capacity, and Temperature. The table displays 15 rows of data, with the first row highlighted in blue.

Time	Input Voltage	Output Voltage	UPS Load	Input Frequency	Battery Capacity	Temperature
2016/08/04 16:05:50	113	113	0	59.9	100	32
2016/08/04 16:05:39	113	113	0	60	100	32
2016/08/04 16:05:29	113	113	0	60	100	32
2016/08/04 16:05:17	112	113	0	59.9	100	32
2016/08/04 16:05:07	112	113	0	59.9	100	32
2016/08/04 16:04:56	112	113	0	59.9	100	32
2016/08/04 16:04:46	113	113	0	59.9	100	32
2016/08/04 16:04:34	112	113	0	59.9	100	32
2016/08/04 16:04:24	113	113	0	59.9	100	32
2016/08/04 16:04:13	112	113	0	59.9	100	32
2016/08/04 16:04:03	113	113	0	59.9	100	32
2016/08/04 16:03:51	112	113	0	60	100	32
2016/08/04 16:03:41	112	113	0	60	100	32
2016/08/04 16:03:30	112	113	0	60	100	32
2016/08/04 16:03:20	112	113	0	60	100	32

### 2.7.1 Setting Machine Name and date of data



This screenshot shows the search bar from the Data Log window. It includes a dropdown menu for "Machine Name" (currently set to "Machine 1"), a text field for "Date" (set to "2016/08/04"), and an "Update" button.

Choose the “Machine Name” and “Date”, click “Search” have the further information.

## 2.7.2 Tools

Work Progress: <input type="text"/>					Export	First	Last
	Time	Input Voltage	Output Voltage	UPS Load	Input Frequency	Battery Capacity	Temperature
▶	2016/08/04 16:05:50	113	113	0	59.9	100	32
	2016/08/04 16:05:39	113	113	0	60	100	32
	2016/08/04 16:05:29	113	113	0	60	100	32
	2016/08/04 16:05:17	112	113	0	59.9	100	32
	2016/08/04 16:05:07	112	113	0	59.9	100	32
	2016/08/04 16:04:56	112	113	0	59.9	100	32
	2016/08/04 16:04:46	113	113	0	59.9	100	32
	2016/08/04 16:04:34	112	113	0	59.9	100	32
	2016/08/04 16:04:24	113	113	0	59.9	100	32
	2016/08/04 16:04:13	112	113	0	59.9	100	32
	2016/08/04 16:04:03	113	113	0	59.9	100	32
	2016/08/04 16:03:51	112	113	0	60	100	32
	2016/08/04 16:03:41	112	113	0	60	100	32
	2016/08/04 16:03:30	112	113	0	60	100	32

**Export** : Click to export the current data into “xls” or “txt” format.

**First** : Click to go to the first recorded entry.

**Last** : Click to go to the last recorded entry.

## 2.8 Event log

The “Event Log” provides a list of records of all the events & tasks to be performed by the program and those that had occurred on each day of the particular month. It provides a summary of the Utilities conditions and UPS testing results.

Machine Name: AllDate: 2016/08Update

Filter

☐ UPS Connected☐ Battery Failed☐ Power Restored

☐ UPS Disconnected☐ Self Test☐ Shutdown OS

☐ Power Fail☐ UPS Shutdown

☐ Battery Low☐ Over Load

Select All

Clear

Filter

Work ProgressExportFirstLast

	Data Time	Machine Name	Event
▶	2016/08/03 17:04:48	Machine 1	UPS Disconnected
	2016/08/04 08:33:10	Machine 1	UPS Disconnected
	2016/08/04 11:34:16	Machine 1	UPS Connected
	2016/08/04 11:35:06	Machine 1	UPS Connected
	2016/08/04 11:36:10	Machine 1	UPS Connected
	2016/08/04 14:49:39	Machine 1	UPS Connected
	2016/08/04 14:50:45	Machine 1	UPS Connected
	2016/08/04 15:28:05	Machine 1	UPS Connected
	2016/08/04 15:33:39	Machine 1	Power Fail
	2016/08/04 15:38:00	Machine 1	UPS Connected
	2016/08/04 15:40:26	Machine 1	Power Fail
	2016/08/04 15:50:07	Machine 1	UPS Connected

### 2.8.1 Setting Machine Name and date of data

Machine Name: AllDate: 2016/08Update

Choose the “Machine Name” and “Date”, click “Search” to have the further information.



## 2.8.2 Filter

Filter

☐ UPS Connected

☐ Battery Failed

☐ Power Restored

☐ UPS Disconnected

☐ Self Test

☐ Shutdown OS

☐ Power Fail

☐ UPS Shutdown

☐ Battery Low

☐ Over Load

Select All

Clear

Filter

Please select or unselect the desire parameters by clicking on the respective parameter field box. Click “Filter” to have further information.

**Select All** : Field box of all events will be “ ☒ ”

**Clear** : Field box of all events will be “ ☐ ”

**Filter** : Click “Filter” the data will show respectively.

## 2.8.3 Tools

Work Progress		Export	First	Last
	Data Time	Machine Name	Event	
▶	2016/08/03 17:04:48	Machine 1	UPS Disconnected	
	2016/08/04 08:33:10	Machine 1	UPS Disconnected	
	2016/08/04 11:34:16	Machine 1	UPS Connected	
	2016/08/04 11:35:06	Machine 1	UPS Connected	
	2016/08/04 11:36:10	Machine 1	UPS Connected	
	2016/08/04 14:49:39	Machine 1	UPS Connected	
	2016/08/04 14:50:45	Machine 1	UPS Connected	

**Export** : Click to export the current data into “xls” or “txt” format.

**First** : Click to go to the first recorded entry.

**Last** : Click to go to the last recorded entry.

## 2.9 Schedule

“Schedule” allows user to create a desire routine to notify UPS to perform specific or repeatable tasks automatically at predetermined dates & times.

Please refer to the following instructions to create an entry :

The screenshot shows a window titled "Schedule" with a table of tasks and a control panel at the bottom. The table has columns for Machine, Date, Time, Day, Task Name, and Frequency. The tasks listed are:

Machine	Date	Time	Day	Task Name	Frequency
[Machine 1]	2017/07/04	10:25	Tuesday	UPS test 10 second	Once
[Machine 1]	2017/07/04	10:25	Tuesday	UPS test 1 minute	Daily
[Machine 1]	2017/07/04	10:25	Tuesday	UPS test till 20	Weekly
[Machine 1]	2017/07/04	10:25	Tuesday	UPS test till LOW	Monthly
[Machine 1]	2017/07/04	10:25	Tuesday	Shutdown OS & UPS	2017/07/04 10:27 Tuesday Turn on UPS Once
[Machine 1]	2017/07/04	10:25	Tuesday	Shutdown OS & UPS	Daily

Below the table, there are three input fields for "Next Test Time", "Next Shutdown Time", and "Next Restart Time", all showing "7/4/2017 10:25:00 AM". To the right of these fields is a red-bordered box containing four buttons: "Add", "Delete", "Edit", and "Exit".

**Create :** Click “Add” to create a new task.

**Edit :** Step1. Choose the task from the schedule list, the highlighted blue bar is the chosen task.

Step2. Set Machine and schedule items.

Step3. Click “Edit” to modify your selection.

**Delete :** Choose the task from the schedule list, the highlighted blue bar is the chosen task.

Click “Delete” to delete the task you choose.

**Exit :** Exit the Schedule

2.9.1 Add

A

Date : 2017/07/04 Tuesday  
Time : 10:27  
Machine : Machine 1  
Frequency ☒ Once ☐ Daily ☐ Weekly ☐ Monthly

B

Control  
☒ UPS Self-Test 10 Secs  
☐ UPS Self-Test(1-99) 1 Minutes  
☐ UPS Self-Test Until Battery Capacity 20  
☐ UPS Self-Test Until Battery Low  
☐ Shut Down Operating System and UPS ☒ Turn On UPS

C

Add Cancel

OS & UPS Shutdown : 2017/09/13 15:42  
UPS Reboot : 2017/09/13 15:44  
Machine : Machine 1  
Frequency ☒ Once ☐ Daily ☐ Weekly ☐ Monthly

Control  
☐ UPS Self-Test 10 Secs  
☐ UPS Self-Test(1-99) 1 Minutes  
☐ UPS Self-Test Until Battery Capacity 20  
☐ UPS Self-Test Until Battery Low  
☒ Shut Down Operating System and UPS ☒ Turn On UPS

Add Cancel

OS & UPS Shutdown : 2017/09/13 15:42  
Machine : Machine 1  
Frequency ☒ Once ☐ Daily ☐ Weekly ☐ Monthly

Control  
☐ UPS Self-Test 10 Secs  
☐ UPS Self-Test(1-99) 1 Minutes  
☐ UPS Self-Test Until Battery Capacity 20  
☐ UPS Self-Test Until Battery Low  
☒ Shut Down Operating System and UPS ☐ Turn On UPS



Add Cancel

- A. Executive Time :** Machine Name : Choose the machine.  
 Date : Date Setting.  
 Time : Time Setting.  
 OS & UPS Shutdown : Set the shutdown time for OS & UPS.  
 UPS Reboot : Set the restart time for UPS.  
 Frequency: Set execute cycle of the schedule.
- B. Control :**
1. Self-test for 10 seconds.
  2. Self-test for 10 minutes.
  3. Self-test til under xx%
  4. Self-test until battery low.
  5. Shutdown the OS & UPS.  
 Restart the UPS after Shutdown in X minutes .
- C. Function :** Add Or Cancel

## 2.9.2 Edit

The screenshot shows a 'Task' configuration window. It is divided into three main sections highlighted with colored boxes:


- Section A (Red box):** Contains the 'Task' title bar, a date field set to '2017/07/04 Tuesday', a time field set to '10:25', a 'Machine' dropdown menu set to 'Machine 1', and frequency radio buttons for 'Once', 'Daily', 'Weekly' (selected), and 'Monthly'.
- Section B (Blue box):** Contains the 'Control' section with several radio button options:
  - ☐ UPS Self-Test 10 Secs
  - ☐ UPS Self-Test(1-99) 1 Minutes
  - ☒ UPS Self-Test Until Battery Capacity 20
  - ☐ UPS Self-Test Until Battery Low
  - ☐ Shut Down Operating System and UPS ☒ Turn On UPS
- Section C (Green box):** Contains two buttons at the bottom right: 'Edit' and 'Cancel'.



- A. Executive Time :** Machine Name : Choose the machine.  
Date : Date Setting.  
Time : Time Setting.  
OS & UPS Shutdown : Set the shutdown time for OS & UPS.  
UPS Reboot : Set the restart time for UPS.  
Frequency: Set execute cycle of the schedule.
- B. Control :**
1. Self-test for 10 seconds.
  2. Self-test for 10 minutes.
  3. Self-test til under xx%
  4. Self-test until battery low.
  5. Shutdown the OS & UPS.
- Restart the UPS after Shutdown in X minutes .
- C. Function :** Edit Or Cancel

## 2.10 Oscillograph

The “Oscillograph” provides a summarized report of the recorded UPS operating data. The recorded data are represented in line curves to provide an easy to read summary of the Utility & UPS power quality.



### 2.10.1 Tools

Machine Name:  Date:

Data Name:  Time zone:

Range :


☐ Input Voltage ☐ Input Frequency

☐ Output Voltage ☐ Battery Capacity

- Machine Name** : Choose the machine which you want to show.
- Date** : Set the date of data you want to show.
- Data Name** : 5 items can be chosen: “ALL”, “Input Voltage”, “Output Voltage”, “Input Frequency”, “Battery Capacity”.
- Time zone** : Choose the time interval.

## 2.11 Pop up alarms for Power Abnormal

When UPS happens one of Power Fail, Battery Low, Battery Failed, and Overload, it will show alarm window in order to remind user to prompt handle.



## 2.12 About

Click About to see the software version.  
Click “Help” to read the user manual.

